

SHORTCUT KEY List - ZofzPCB 1.3			
	Description	Ctrl- (Shift-)	Description
ESC	Remove distance markers, net highlights, cross-cut. Exit from menus.		
F1	keyboard and Mouse Help		
F3/F4	Emulates mouse wheel roll action +/- layer peel or spread - depend on layer mode		
F5	Set Zoom Mode	Ctrl-F5	Reset Peel/Spread mode and set Zoom Mode
F6	Set Layer Peel Mode (works on both sides independently)	Ctrl-F6	Reset Peel/Spread mode and set Peel Mode
F7	Set Layer Spread Mode	Ctrl-F7	Reset Peel/Spread mode and set Spread Mode
1..9, 0	Go to position marker 1...9, 0	1..9, 0	Save position marker 1..9, 0
TAB	IN PCB compare mode: circle view - PCB1 / PCB2 / Diff	Ctrl-TAB	Level camera horizontally (set PCB as Ground Level)
W, S	Camera Pitch Down, Up	Ctrl – slow Shift - fast	
A, D	Camera Yaw Left, Right		
Z	Flip PCB to other side		
X	Center PCB without Rotation		
<space>	Rotate camera to nearest rectangular angle		
E	Set measurement Marker at the shape Edge pointed-inside by the mouse pointer		
T	Set measurement Marker at the Track pointed by the mouse pointer		
P	Set measurement Marker at the Pad pointed by the mouse pointer		
H	Set measurement Marker at the Hole (drill) center pointed by the mouse pointer		
N	Highlight Net pointed by the mouse pointer	Ctrl-N	Circle Net Selection Effects
		Ctrl-C	Copy content of measurement text to the clipboard
Home	Position camera in front of the PCB	Ctrl-Home Shift-Home	also reset rotation also reset to top side
←, →	Shift Camera left, right	Ctrl – slow Shift - fast	
↑↓	Shift Camera up, down		
PgUp PgDn	Shift (zoom) camera forward, backward		
Num * Num /	Roll camera counterclockwise, clockwise Alternatively use [and]	Ctrl - Num * Ctrl - Num /	Roll camera counterclockwise, clockwise; to the nearest 90°
INS	Toggle 3D Mouse® mode between camera mode and object mode		
DEL	PCB Cut Section at mouse pointer. First drag to set angle, second press and drag to shift the cut	Ctrl – free angle (no Ctrl – angle every 45°)	